




VT80BL Instruction Manual



Specifications:

Nominal thrust:	80N at 150.000 RPM
Idle thrust:	4,5N
Idle RPM:	45,000
Diameter:	90,5mm (3.56")
Engine weight:	950g (2.1lb)
Installed weight:	1,075g (2,37lb)
Fuel:	Kerosene + 3% - 5% oil
Fuel comsumption:	220g/min
Start mode:	Direct Kerosene

INDEX

Welcome.....	Page 3
Legal and Disclaimer.....	Page 3
Disclaimer.....	Page 3
Warranty.....	Page 4
Safety Notes.....	Page 5
Engine Description.....	Page 6
Installation Notes.....	Page 6
Electronic Control Unit (ECU).....	Page 7
Smart Data terminal.....	Page 7
Engine installation: Electrical connections.....	Page 7
Engine installation: Fuel system.....	Page 8
Fuel filter.....	Page 8
ECU (Engine Control Unit) Set Up.....	Page 8
Aligning transmitter with ecu.....	Page 10
Failsafe.....	Page 11
Preparing the engine for running.....	Page 11
Prevent flood engine.....	Page 12
First engine runs.....	Page 12
Priming the fuel system.....	Page 13
Starting the engine.....	Page 13
Engine shut down procedure.....	Page 13
WHAT TO DO IN THE CASE OF AN EMERGENCY.....	Page 14
List of ECU message codes.....	Page 14
Diagnoses.....	Page 15
Diagnosis messages.....	Page 15
VT80BL Trouble Shooting.....	Page 15

Other useful information and installation tips

Fuel System.....	Page 16
Fuel and Oil.....	Page 17
Feed Pipes.....	Page 17
Extra ECU functions.....	Page 18
Maintenance.....	Page 19
Running Time Counters.....	Page 19
Autorestart Function.....	Page 20
Smart Data Terminal.....	Page 23

JETS MUNT S.L

Torrent d'en Puig, 31.08358, Arenys de Munt, BARCELONA, Spain

Tel/Fax: +34 93 7950113

www.jetsmunt.comE-mail: info@jetsmunt.com.

© Copyright 2012, Jets Munt SL. All Rights Reserved



Welcome!

Congratulations on the purchase of your new Jets Munt VT80 gas turbine engine. Jets Munt are dedicated to the design and production of engines to the highest standards of quality and reliability to bring you the customer the very latest next generation engine designs.

The VT80 is the result of an intensive effort of design and tests by the Jets-Munt staff. During the development period we made extensive use of the latest Computational Flow Dynamics programs allowing us to optimise the engine performance characteristics.

PLEASE READ!

**The Jets Munt SL responsibility is limited exclusively to the repair of the engine and accessories which are outlined in the conditions of warranty.
Before unpacking the engine please read the manual, and agree to the conditions of warranty.**

Customer satisfaction is important to Jets Munt SL. Technical support is available through your local dealer and through email.

Jets Munt S.L
Torrent d'en Puig 31
08358 Arenys de Munt
Barcelona. Spain
Web site: www.jets-munt.com
E-mail: info@jets-munt.com
Fax: +34 93 7950113

Legal and Disclaimer

The engine design and the contents of this manual are copyright by Jets Munt SL, Arenys de Munt, Barcelona, Spain. All rights reserved.

This manual, the pictures and data are property of Jets-Munt and cannot be used or reproduced in any way without written permission from Jets Munt SL.

Disclaimer

The VT80BL engine is a sophisticated piece of machinery. Care should be taken at all times when using the engine. It should only be operated by those with the appropriate skills and knowledge to do so. This engine is not a toy. Incorrect operation or misuse can cause damage to property and bodily harm operators, spectators and animals. Jets Munt SL accepts no liability for any kind of damage which may occur.

Jets Munt SL assumes no responsibility for any errors contained in this document and is not liable for any damages resulting from such errors.

It is forbidden the use of this engine outside Radio Control applications,
specially those that power vehicles that carry people.



Warranty

The warranty period for the VT80 is 2 years from the date of purchase, or 25 running hours, whichever comes first. Warranty is valid solely for the original owner and is non transferable upon resale.

Warranty includes all supplied parts, and is limited to manufacturing and material defects only. Shipment costs, including packing and customs fees are not covered by the warranty and will be always at owner expense.

Damage or defective operation covered under the warranty terms will be repaired and tested at no cost the original owner (other than shipping expenses). Repairs not covered under the terms of warranty will be carried out by Jets Munt SL or their appointed agents after agreement of costs.

Before returning the engine or ancillary equipment for service of repair, please contact first to your local dealer or Jets Munt central office to agree action and costs.

Please do not disassemble this engine or any other item supplied. You will breach your warranty agreement and you will find it is a precision assembly which you will be unlikely to re-assemble without considerable difficulty and specialist equipment. Simply slackening the spinner nut of the rotor will immediately lose the delicate balance condition, without which the engine may not run without damage to its rotating assembly.

This warranty is void if any one or more of the following conditions applies. In such a case Jets Munt will accept no responsibility for any damage or any other consequence caused by the VT80 operation.

1. The product has been subject to any form of operation whilst containing incorrect fuel, oil, or fuel/oil mix.
2. The product is crash damaged, pump is blocked due dirt ingestion, electronics or pump are flooded by fuel, connection leads are cut or lost its isolation and short-circuit, reverse polarity on battery, etc.
3. Unauthorized maintenance or modifications have been made to any part of the product, including the unlocking of the ecu and changing the manufacturer settings or any of the items supplied has been disassembled.
4. Parts have been damaged by ingestion of foreign objects (e.g. wires, sand, water etc).
5. The engine has been operated incorrectly.
6. The product has been misused, neglected or inadequately maintained.
7. Damage to the engine where blockages in the fuel system have occurred by unfiltered or contaminated fuel.

Jets-Munt Representatives:

Check the current dealer list on our web page, www.jetsmunt.com



Safety Notes

Please remember the engine is not a toy and has the potential to cause bodily harm to you and others if misused. The VT80 is a sophisticated piece of machinery and should be treated with a high level of safety when it is in operation.

The following guidelines should be read carefully and adhered to.

1. Always keep a CO2 or similar fire extinguisher of at least 2Kg of CO2 contents close when starting and operating the engine
2. Always protect eyes and ears during the starting procedure.
3. Be aware of the extreme intake suction hazard, we advise the use of a suitable commercial wire mesh Foreign Object Damage guard to protect the engine intake. Ensure you have no loose items of clothing (ties, etc.) or equipment which can readily be sucked into the engine intake, even from adjacent to the engine.
4. Always operate your engine in open air away from confined spaces as the engine exhaust contains gases which can cause asphyxiation and nuisance smells.
5. Do not touch the engine whilst it is running. Turbines rotate at a very high rpm and the engine casing and exhaust can reach very high temperatures. Ensure anything affected by heat is kept well clear of the engine and exhaust during operation.
6. Never use the engine near to sources of flammable gases, liquids or materials.
7. Keep unauthorized persons, spectators, children and animals well away from the starting area (at least 30ft or 10 meters away).
8. Always handle turbine fuel and oil with care as they are highly flammable. Store them in appropriate labeled containers. Never dispose inappropriately. We recommend the use of suitable disposable protective gloves for the mixing of turbine oil/fuel.

VT80 Specifications

Dimensions: Outer Diameter 90mm; Length: 240mm

Weight: 950grams (engine only). 1075gr including pump and mountingstrap

Nominal thrust @ 15C and sea level: 80N

Max.RPM: 150,000 rpm

Idle RPM: 45,000 rpm

Idle thrust 4N (0.8lbf)

EGT @ max rpm 550-650 °C

Fuel consumption 0.29 l/min at 80N

Fuel/ oil: Kerosene + 4% Oil See page 17 for oil types and percentages

Engine Description

The engine is a turbojet of a single shaft design specifically designed to power RC aircraft. The engine starts automatically thanks to an installed electric starter situated in the front.

The starting sequence is controlled by an electronic unit that initiates the starting sequence and controls the parameters of the engine within the design limits.

The engine uses a system of direct liquid preheating, ignited by a long life ceramic glow plug situated inside the engine. After the initial preheat the liquid fuel is gradually introduced.

The fuel should contain a small percentage of oil and uses part of this fuel to lubricate its two ceramic high speed bearings.

The fuel for the engine is provided from a fuel tank through a small electrical pump. The engine speed between idle and maximum is controlled by varying the speed of the fuel pump through an electronic controller called an ECU (electronic control unit), that is contained inside the engine.

Installation Notes

1. The engine should be mounted using the strap mount supplied or an approved equivalent.
2. The signal cables from the engine must be carefully routed away from the engine intake so there is no possibility of accidental ingestion of the wire.
3. Fuel pipe should be routed similarly clear of the intake.
4. The fuel pump should be preferably mounted with the spindle in the vertical position with the motor uppermost. In the event of any fuel seeping from the pump this will not pass through the electric motor. Note the pump is supplied fitted with built in suppression filter to reduce radio frequency noise.
5. The centre of the fuel tank should be mounted laterally, as near to the centre of gravity (CofG) of the model as possible. This will minimize the CofG shift as the fuel is used during flight.
6. Any air ducting to the inlet of the engine must have sufficient diameter of at least twice of the engine intake diameter.
7. If an extended exhaust duct is required, it should be of sufficient diameter and strength for optimum engine performance.
8. Extreme care should be exercised to ensure that no foreign object, loose parts of the model or debris are allowed to enter the compartment where the engine is installed. We recommend testing the engine on a test stand prior airframe installation. You should have a clear idea of how to arrange the components needed to run the engine inside the model. The main issue is the fuel tank, you will need to arrange the CofG in the centre of the tank and adjust the receiver and ECU batteries to achieve the correct location.

Electronic Control Unit (ECU)

The ECU integrated inside the engine is custom designed for the VT80 engine and must not be changed for any other, as this may result in improper control of the engine. Your engine has been set up and run with this ECU at the factory and the settings should be left as default. The ECU plugs into your receiver throttle channel and is powered from the receiver rechargeable battery. The ECU is pre-programmed and only requires simply setting to your radio.

Smart Data terminal

The Smart Data terminal plugs into the ECU via the lead supplied. The display can be installed permanently on board. This socket also doubles as digital connection to a computer.

The Smart Data terminal includes dedicated screens for radio checking, last shutdown cause and other special turbine operations. The most innovative and useful function is the internal recorder/playback function. The terminal continuously stores all the data received from the ecu, keeping in its permanent memory all the data of last 66 minutes of engine run, without the need of the memory card. After the flight, the terminal can be pulled out of the plane and, without connecting to the ecu, just using an 5-10V battery, the data stored can be played back in real time, same presentation as if the engine was running. Playback mode can be still, forward or reverse, speed x1, x 10 and x100 in both directions, so that would be easy to investigate any issue at the field without the need of a computer or any other type of reader.




Data, including all engine parameters, can be saved later to a memory card, where it can be read using a text editor, or our viewer software. Also can be sent to engine manufacturer to be studied, and changes uploaded back to the ecu.

Check the instructions on page 23. The function of the buttons is described later in the "ECU setup".

Engine installation: Electrical connections.

Connect the battery to the Multiplex socket "MPX", connect the throttle channel from your receiver to the socket "Throttle", connect the brushless pump to the socket "Pump" and the smart data terminal to the socket "Terminal".



PLEASE: DOUBLE CHECK THE BATTERY POLARITY BEFORE CONNECTING IT TO THE ENGINE.

A reverse polarity connection will immediately damage the electronic components inside the engine.

Recommended battery is a LiPo of 7,4V and at least 2000mAh /15C. Optionally is possible to use an A123 battery of 9,9V, although the engine is happier with 7,4V. 3s Lipo is not supported.

Engine installation: Fuel system

Install the fuel system components as seen in the picture:

Connect the fuel pump to the ecu. Check the colors. If connector is placed reversed, the pump will run backwards.

Pump: Note that the fuel pump has an arrow engraved in the front face indicating the direction of the fuel flow.

Never disassemble the fuel pump, warranty from pump manufacturer will become void.

Fuel filter

The fuel filter must be installed close to the input port on the pump to prevent any particle to enter in the pump and to damage it. Use a suitable length of the 4mm clear tubing supplied, keep the tubing on the suction side as short as possible. Direction of flow inside the filter is not important, but should be always the same after first use.

Do not run the engine without the fuel filter.

Finally connect the fuel pump engine as shown. The fuel pump is a delicate element, dropping it on the floor can damage it, always handle with care and install using the provided mount, leave the motor part loose so that it don't move in respect to the pump part.

It is strongly recommended that, after a new installation or modification on the fuel system, to disconnect the fuel hose from the engine, routing it to a appropriate container, and run the pump few seconds using the "pump test function" on the ecu so that some fuel clean all the possible dirt particles that could have entered in the system during installation.

ECU (Engine Control Unit) Set Up

The ECU supplied is supplied programmed for the VT80. The engine has already been set up and tested using the same ECU and pump supplied so there is very little to adjust in order to get the engine running. Confirm you have connected the ECU input to the throttle channel of your receiver, DISCONNECT the ecu battery, and connect the Data Terminal into the ECU. Remove all rates, mixes and throttle travel settings in the transmitter. Before doing any adjustment on the ecu, check that your transmitter is sending the correct signal by checking the reading of "Pulse" in the data terminal. It should be between 900-1050uS at STOP, position, between 1100 and 1300uS at IDLE position and between 1800 and 2200 at Full Power position. Please note that these readings on the ecu are measured directly from the signal received from your RC system, so you should readjust your transmitter if the values read are outside that the ones suggested.


The setup assumes the use of a transmitter with manual trims.

**If you use a TX with digital trims, is essential to use the switch in the TX programmed for the function "Throttle cut", or "engine cut" which normally has the effect of producing the "trim-down" function. Using a digital trim cause unstable idle, and excessive delay in shutting off the engine in emergency.
Check your radio manual for this before you start. DO NOT use the digital trim in any case.**

Engine installation: Electrical connections.



Engine installation: Fuel system



Aligning transmitter with ecu

As the display does not photograph well we have reproduced the display readings as a green box.

(1)

Trim Low T=020°C
RPM 00000 PW 000

Turn on the transmitter and receiver. The opening screen should show as (1):

Note there are four buttons on the display, two on the left and two on the right hand side. The left buttons move to the different screens and the right buttons are used to change the values stored. Press the second, left button and scroll through the menus until you find the one showing (2):

(2)

Info Run
Start Radio

Press the (-) button and the ecu will show the “Radio” parameters menus. First screen show graphically the current adjusts on the radio. Press the (-) button again to enter in the menus to adjust the radio (3).

(3)

Transmitter yes
adjust

Press the right hand button (+) to confirm that you really want to program the radio. The screen will change to (4):

(4)

Stick Up Trim Up
(Full power) Ok

On your transmitter, raise first the trim to full and next the throttle stick to full, in this order. Ensure stick is firmly against the stop. Now holding the stick against the stop, press the right button (+) to store the signal from your TX into the ECU. The screen will now change to (5):

(5)

Stick Down Trim Down (Stop) Ok

Move the trim (or switch the “engine cut” switch to on) and throttle stick back to zero and again press the right hand button (+). The display will now change to (6):

(6)

Stick Down Trim Up (Idle)

Leaving the throttle stick in the minimum position, raise the throttle trim to the full up position or switch “Engine Cut” switch to off, and again press the “+” button to store the value into the ecu.

(7)

Pulse=1000uS 0%
Battery: 7,2V

If you have done all steps correctly the LED located directly above the throttle socket in the ecu will light up flashing 2 times in the ECU when the “Idle” command is received, meaning that trim and throttle stick are set to idle positions on the transmitter. If the ecu battery is connected, a sound will be heard at same rate as the Led blinks. Lower your throttle trim and the LED will change to a single flash sequence indicating correct reading of the transmitter engine shut off signal by the ecu.

On some Futaba transmitters, it has been found that the throttle channel the sense of movement may require reversing (Servo reverse) and repeat the transmitter alignment. Correct reading of throttle % by the ecu can be verified in the second screen of the data terminal (7), percentage of the throttle position is shown on, 0% in the position of engine stop (trim and stick down), 100% with stick/trim full up and between 10% and 30% at idle. This now completes your radio setup and should only need doing again if the radio settings are changed.

Failsafe:

Never fly with the failsafe set to “hold”. It is strongly recommended that you setup your radio system with the correct failsafe settings. In some countries is mandatory that the engine stops in 2 seconds in the case of a failure of the radio link.

To program correctly the failsafe on your radio:

- 1) Adjust the travel of the throttle channel from -100% (stop position) to +100% (full power)
- 2) Adjust the ecu to your radio as described above.
- 3) Adjust the failsafe position of the throttle channel in your radio to a -125%.

If all is correctly adjusted, the ecu will stop the engine immediately when receive the STOP signal (-100%), but if the signal received is Failsafe (-125%) the ecu will set Idle power during 2 seconds, and, if after these 2 seconds the Failsafe condition persist, will shutdown the engine.

Once you have the radio programmed, you can check it by setting the throttle to the different positions, including switching off the transmitter; in this case the “failsafe” reading should be displayed.

There are many more parameters that can be modified in the ECU, but we have specifically programmed your VT80 ecu with the optimum settings, further adjustment should not be required and can only be carried out by Jets Munt SL or your authorized dealer.

Preparing the engine for running

A suitable platform/table/workbench is now required to clamp the test stand onto. Make sure this can be easily transported outside and weight enough to ensure it cannot be blown over by the thrust of the engine.

Select a clear area for running – keep clear of areas with loose leaves, sand or other debris that could be picked up or drawn towards the intake. Ensure the fuel tank is position well clear of the exhaust area and secured.

Important notes for kerostart engines. **PLEASE READ**

The kerostart system used on this is a reliable and well tested that produce very smooth and trouble free starts.

However, extra care and attention must be paid when starting a kerostart engine. The main difference between gas and kerosene is that in the case of a failed ignition, the gas dissipates quickly on the air and don't keep inside the engine. Kerosene is liquid and, if unburned, will pool inside the engine and stay there forever. The engine can hold a big quantity of kerosene inside. This kerosene will be ignited on next successful start up and will be pushed to the exhaust as soon as the airflow inside the engine is sufficient, and will be ignited in the exhaust, causing a hot start (in extreme cases a big fireball) that surely will not hurt the engine, but can destroy the model.

Prevent flood engine:

During the start-up listen to the engine sound to check for positive sound of ignition, check looking from the exhaust that the kero is burning, or check for a increase in exhaust temperature in the data terminal. A small plume of white smoke from the exhaust means that the fuel is not burning. The fuel is pooling inside the engine. Abort immediately the start.

Double check that the engine is not flooded. A extra security measure is to place a manual valve between the last fuel tank and the pump intake line, to prevent that during the process of filling the tanks or during storage, some fuel can arrive to the engine.

After a failed start, or whatever condition that could cause that fuel be collected inside the engine (i.e. extra priming), ALWAYS empty the engine of fuel by tilting the engine nose down. Fuel will exit trough intake. Do not tilt upwards; due at the internal engine construction the fuel cannot exit trough exhaust.

Another big difference between gas start and liquid start is that the kerosene can keep slowly burning during long time inside the engine. This situation usually happen during an aborted start, the start-up sequence is aborted by the user or automatically before the engine arrive to idle. This can cause that the kerosene inside the engine keep burning for long time, and could destroy the engine or the model. **IF A STARTUP SEQUENCE IS NOT COMPLETED, ALWAYS CHECK FOR FLAME INSIDE THE ENGINE.** If there is flame, then set full throttle for over 3 seconds to engage the starter and blow out the flame. USE SHORT BURSTS OF STARTER. Using the starter for long time can destroy the starter motor. In the case that the start-up procedure has been aborted due at starter failure, then it will be necessary to apply the CO2 fire extinguisher. A white smoke from the engine is a good indication here; mean that there is no fire inside.

First engine runs

- Confirm your test stand is securely fixed to a bench or heavy table. Keep your ear defenders within easy reach and a CO2 fire extinguisher handy. **VERY IMPORTANT ON KEROSTART ENGINES.**
- Fill the fuel tank. Do not forget to filter the fuel, and to mix the oil.
- Confirm all batteries are freshly charged and connected up.
- Check there is a temperature reading on the data terminal.
- Ensure the running area is clear of onlookers – especially the prohibited zone of a 10 metre radius 180° arc from engine centre around the rear.
- Verify that the fuel tube is full of fuel and purged of all air, if not, carry out the fuel prime sequence as described here.

Priming the fuel system:

Fuel line need purging of all air after initial installation. Take extra care when priming them, ensure fuel is primed only up 5cm before to reach the engine; too much fuel inside engine will cause excessive flaming during start sequence.

Priming is achieved by a special menu on the ecu. Set the trim to low and go to "Info" menus and next to "Pump test". Click on "on" /"off" to start/stop the pump manually. Please observe fuel line to engine very carefully and push the off button to shutoff as soon as fuel reaches engine..

IMPORTANT: The prime procedure should be done only to fill the fuel tube and filter in the case of a first installation or in case of disassembling of the tubes. Do not run the prime function so that the engine becomes flooded by fuel, as this will cause an uncontrolled fire at next startup.

Starting the engine

Set the throttle stick down and the trim up. "Idle" - Confirm that the LED in the ecu is blinking in a sequence of 2 blinks and the screen shows "Ready" - !Ready to start!.

Move the stick to full throttle and then back to idle again. The Ecu will begin the startup sequence as described below:

First the internal glow plug will be energized. After 3 seconds, the starter will be powered up to have the rotor turning at slow speed (2000- 3000 RPM).

Once the rotor is at speed, the pump and solenoid valves will be energized in pulsating mode. Few seconds later the kerosene will ignite and the exhaust temperature will begin to increase. The rpm and pump power will increase automatically. During this phase the data terminal will display "IGNITION". When the ignition is detected, the data terminal reading will change to "Preheat", during this phase the fuel will be routed to main injectors and the speed of the rotor will be progressively increased to 12,000 RPM.

Once this phase is finished, the reading will be "FUEL RAMP". In this phase the engine receives fuel only trough its normal fuel input and internal glow plug will be disconnected. The fuel flow and starter power will be increased automatically to increase the RPM up to idle RPM. Before arriving to idle the Ecu will automatically disconnect power to the starter. When the rotor speed reaches idle, the screen will change to "running" and the engine speed is stabilized.

The engine is running!

Control of engine power/rpm is now handed back to the transmitter and controlled by the position of the throttle stick. Increase/decrease the throttle slowly, verifying that the engine accelerates/decelerates. Take special care around the engine intake; keep your hands at a safe distance along with any other objects as they can be easily ingested.

Engine shut down procedure:

To shut down the engine lower the trim and the stick. Is recommendable that before shutting down the engine please restrain the model then raise the throttle stick to approximately 25%, allowing temperatures to stabilize for around 5 seconds before carrying out the shutdown procedure.

WHAT TO DO IN THE CASE OF AN EMERGENCY

During the start sequence the Ecu will be in charge of everything, controlling temperature and RPM. The only thing the user can do is to abort the sequence by lowering the trim in the case that something abnormal (excessive flames in the exhaust, etc).

If a problem is detected, first:

Move the trim to the low position to abort the sequence.

If there is a fire in the engine and the problem is because the starter has failed or the engine is seized (not turning), **IMMEDIATELY APPLY THE FIRE EXTINGUISHER** through the intake side of the engine, never trough the exhaust.

If there is a fire, but the rotor remains free to spin and the starter is OK, raise the trim and stick to the full power position for 3 seconds, this will connect the starter manually to ventilate the engine and extinguish the fire.

The throttle channel acts as a starter switch.

USE SHORT BURSTS OF STARTER. Using the starter for long time can destroy the starter motor.

List of ECU message codes

Here is a list of possible messages shown on the data terminal screen and their meaning.

TrimLow: Indicates that the signal received from the transmitter corresponds to the lowered trim, that is to say, engine OFF.

Ready: Indicates that the engine is ready for starting, and that the transmitter signal corresponds to IDLE, (LED lit twice)

StickLo!: This indicates that the throttle stick is in a position above IDLE, the engine will not start with the stick in this position.

Glow Test: Verification of glow plug

StartOn: Test of the starter

Ignition: Gas ignition phase.

Preheat: Phase of heating of the combustion chamber after detecting the ignition.

FuelRamp: Phase of acceleration until idle speed.

Running: Engine working correctly, pilot have full control of engine power.

Stop: Engine off.

Cooling: Starter operating to cool the engine.

GlowBad: Defective or disconnected glow plug.

StartBad: Defective starter, insufficient RPM reached during start, RPM sensor damaged.

Low RPM: Engine had been shutdown because the speed has fallen below the minimum.

HighTemp: Excessive temperature

Diagnoses:

During engine operation the Ecu measures and stores all the engine operating parameters recorded during the last the 51 minutes of operation. These measures can be downloaded later to a PC to study the behavior of the engine in flight and to diagnose any possible problems.

Also, after each cycle of operation, the Ecu stores the last cause of shut down and the values of RPM, temperature and pump power. In order to access these measures, it is necessary to shut down and power-up the Ecu. Set the trim down (trimLow) and push the left button on the display. The Ecu will show the cause of last shutdown and the parameters values at the moment of shut down. These are as follows:

Diagnosis messages:

UserOff: The engine has been shut down because it has received the shut down command from the transmitter.

FailSafe: The engine has been shut down because of loss of the control signal from the transmitter. After 0,5s of detecting a loss or invalid RC signal, the ecu sets engine power to idle, and if after another 1,5seconds a valid signal is still not received the engine is shut down.

LowRPM: The engine has been shut down because the RPM has dropped below a minimum. Cause could be lack of fuel, air bubbles, problem with the batteries, or defective RPM sensor.

RCPwFail: Lack of power from the radio receiver.

VT80BL Trouble Shooting

PROBLEMS	SOLUTIONS	PROBLEMS	SOLUTIONS
There is no reading on the screen	1. Disconnected receiver or the ecu/receiver batteries are empty 2. The display is badly connected 3. Problem in the ecu or display	The engine loses power in flight	1. The ECU battery is empty: recharge 2. The filters are dirty
The kerosene does not ignite	1.. Check fuel flow. 2. The battery is discharged 4. Glow voltage or pump power needs adjustment	The engine stops in flight	1. The fuel level is low and/or there is air in the pipes 2. There is a poor connection between the battery and pump 3. Interference 4. Check the "last power down" cause on the ecu
There is little increase of RPM when the fuel ignites	1. There is air in the line of fuel 2. The filters are blocked		
The engine reduces the power of it is stopped during starting	1. The ecu has detected temperatures over 800°C due to too slow starting 2. There is low battery or air in the tubes- Therefore let it cool and retry	There is excessive vibration and unusual noise	1. The engine is unbalanced by the ingestion of a foreign object. Do not use the engine and send it in for service.
Engine does not accelerate to maximum set rpm	1. There is insufficient fuel flow or air bubble entering the engine during the initial start up.	During startup the rotor spin at low speed and "Start Bad" message is issued	1. Incorrect oil used on last run. 2. Low battery voltage 3. starter clutch slipping

Other useful information and installation tips:**Fuel System**

Always use appropriate containers to store fuel. It is advisable to install an anti bubble system to the fuel supply circuit. The simplest one is a felt filter clunk installed into the fuel tank. This helps maintain consistent fuel flow and greatly reduces the possibility of air getting into the suction side of the pump circuit, which could cause stoppages. To prevent the felt element sliding out of position a washer is fitted between it and the feed tube – as seen.



A BVM UAT is another contemporary method of reducing the possibility of air bubbles in the engine fuel line. This is a very important aspect of the operation of any turbine engine. Use an appropriate adapter for the 6mm tube output of the UAT to the 4mm in the inlet side of the fuel pump, direction of fuel flow is clearly shown at the top of the pump. The clear 4mm tubing is used on the pressure side of the pump.



Clear tubing helps identify and locate any potential future problems with air leaks.

The fuel pump and ECU can be mounted simply with a pair of tie wraps and/or Velcro. The best orientation for the fuel pump is vertical. It is important to ensure any fuel seepage does not reach the motor brushes. The fuel feed from the pump to the engine should have sufficient length of the clear tubing fitted to allow the fitment of the electronic fuel shutoff valve and the valve should always go on the pressure side.

When making any fuel or gas line cuts use a sharp blade to make and cut squarely. The fuel filter provided should be installed in an accessible place for regular inspection, close to the intake port of the pump.

Other useful information and installation tips:**Fuel and Oil**

1. Use CLEAN well filtered Jet A1 or kerosene fuel which is available from most airports, or paraffin (K1) used for greenhouses available from most hardware stores.
2. Ensure the fuel is clean and filtered at each stage of mixing and transfer to the model fuel tank.

Please note the importance of using clean fuel. Failure to do so will result in blockages of the fine fuel injectors in the engine or blockage of the engine lubrication system and subsequent bearing damage.

3. Ensure the fuel is free from moisture (water is heavier than fuel and will settle at the bottom of the container).

4. Use good quality oil:

-> Aircraft turbine oils e.g. Aeroshell 500, Exxon 2380, Mobil JetOil II. Mix at 4%

-> Mobil DTE Light turbine oil. Mix at 5%.

-> 2 stroke 100% synthetic oil with a specification JASO FC or better. Mix at 3%

-> Recommended: 3% Mobil DTE Light + 1% 2T Oil (JASO FC)

DO NOT USE TCW-3 oil. TCW-3 is a specification for marine oils and guarantees that it is not poisonous for aquatic life, however not guarantee the oil quality for turbojet engine use.

Important note regarding the 2T oil: The engine can use 2T oil, but the different oil brands use different contents of additives to protect the mechanical parts from rust during inactivity periods. This is good for engine protection, but some oils become too sticky when cold, preventing the starter motor to turn the rotor at correct speed, causing a startup failure (Bad Starter message) or damage to the ecu or starter motor after repeated abuse. We strongly recommend to use turbine oil or our recommended oil mix if you find that the rotor become sticky on cold conditions.

5. The fuel must be mixed with oil in the recommended ratio. Too little oil will shorten the bearings life. You can use higher content of oil (5-6%) without any problem for the engine to share the same fuel with other engines.

Please remember to always handle fuel and oils with care! Avoid all direct contact with skin – in case of contact wash all affected areas with soap and warm water immediately.

Feed Pipes

All the pipes must be Polyurethane or nylon as provided by Jets Munt or Tygon (like the ones used by gasoline engines). Do not use Tygon on the pressure side of the fuel pump. Silicone tubing must not be used anywhere in the installation as it is dissolved by fuel and oil. If in doubt, take a small piece of tube and submerge it in kerosene for a few days and verify that its characteristics have not changed.

Other useful information and installation tips:**Extra ECU functions**

The ecu provides several menus that allow doing some tests and personalizing some settings,

Like:

- Adjust the thrust/throttle curve (Linear, Expo, Intermediate).
- Test the starter, Glow Plug, valves and Pump.
- Check the failsafe counter (time and pulses of wrong RC signal).
- Reduce the maximum power.
- Increase the Idle Rpm.
- Adjust the glow plug voltage. The engine come from factory with this voltage adjusted for reliable starts and long life of the glow plug element. Increasing the voltage beyond the necessary will cause the failure or shortening of the life of the element. Do not change the voltage, please contact to Jets Munt first.
- Adjust the pump power at startup. The fuel flow during ignition phase must be finely tuned for each engine/pump combination, and this is done at factory during test. In the case that after some run time the pump become loose and the starts become too aggressive, reduce the value by 2 units at time until normal starts are reached again.

Other useful information and installation tips:**Maintenance**

1. Always keep the engine and its accessories clean and dry.
2. Regularly check wires for chafing or insulation breakdown etc.
3. Regularly check fuel pipelines for chafing and /or leaks at joints.
4. Check the engine and mounting for loose fittings and secure if required.
5. Ensure the fuel system is kept free from dust and dirt inclusion and that fuel is carefully filtered.

Running Time Counters

Using the second left hand button, scroll through the menu's to the INFO menu.

This screen contains a timer which shows:

The total running time of the engine in minutes (Tot),

The time in seconds of the last engine run (Last)

The total number of starts (cycles - CY).

Use this screen to keep track of your total running time and starts.

A extra timers is provided, called Service Timer, to keep track of the service intervals, it will be reset when the engine is serviced in regular maintenance.

Autorestart Function

Some JetsMunt engine models (currently VT80BL and M100XBL) include AUTO restart function.

This function can quickly restart an engine automatically in Flight, but it should be understood that such a system may cause damage to people and property.

By default this function is disabled in the ecu, the user should expressly enable it. By enabling this function, the user agrees that he/she has understood the working principles and understands its limitations.

Restart options and how to enable them

Within the “Radio” menu, a new choice has been added to define the restart operation.

The ecu offers 3 choices:

- **Standard operation:** After the shutdown the ecu should be reset (power cycled) to enable another startup cycle. Engines are supplied in this mode.

- **Manual Start:** user can normally shutdown the ecu through the transmitter (by lowering the stick and trim). The ecu will execute the normal shutdown and post run cooling. Once the cooling is finished (temperature below 100°C), the ecu will return to power-up state, allowing the engine to be restarted through the normal procedure (Trim-up, cycle stick). The time to shut down and later start is exactly the same as standard operation. This mode is useful for gliders, where the engine is used to climb to height, shutdown, soaring, restart, climb, etc. This mode does not pose any safety hazard.

- **Autorestart:** In particular case of a fuel bubble that momentarily stops the combustion, the ecu will detect this condition by monitoring the rpm, temperature and pump power, the ecu triggers the auto restart sequence. This sequence is done with the engine hot, so the power is restored quickly. This restarting function can help save the plane in few limited circumstances, but it can also greatly increase the risk of fire, so before to enable this function, please read and understand the following:

What does the auto-restart function do

It automatically tries to restart the engine quickly and restore the power setting that is being asked by the transmitter.

To trigger this function, the ecu checks:

- The radio signal is valid, no failsafe condition.
- The readings of the RPM are consistent with a flameout condition (the speed of the RPM coasting down is between preset limits).
- The readings of the EGT are consistent with a flameout condition.
- The battery voltage is good.
- No other faults detected.

Once the ecu is satisfied that the shutdown/flameout was most likely caused by an interruption of combustion, usually caused by an air bubble, the ecu triggers the quick restart function, where the ignitor is energized to full voltage and the pump is started at a power dependent of the current engine status (RPM and EGT). Once the ecu detects that the combustion has reassumed, the starter power is set to full power to reach the idle rpm as quickly as possible, and the pump power is increased accordingly to the real RPM increase, allowing for delays caused by bubbles arriving to the engine. If after 10 seconds of restart the ecu doesn't detect a stable combustion, the procedure is aborted and the normal cooldown initiated.

What the autorestart function will not do

- It will not restart the engine if the shutdown was caused by any fault other than a typical flame out caused by air in the fuel system.
- It will not monitor and confirm flight conditions are optimum for a restart. Leaving the restart to progress is the pilot responsibility and decision, depending on each particular case.

When should Re-Start function be Enabled?

Restart takes an average time of 15s to establish restored level of pre-shutdown power. It is highly recommended that Re-Start only be used on airframes capable of sustaining enough flight for the re-start to be complete. Some aircraft examples include: lightly loaded planes, gliders, or multiengine planes.

It is highly advised a shutdown simulation be done before selecting Re-Start option in the ECU Menu. Do this during a normal flight at a high altitude and throttle down to idle then begin a 15sec count down. From this try to gauge if the aircraft can maintain flight during this low power setting.

If your plane cannot maintain flight for a minimum of 15sec without engine power, do not enable the restart function.

I'm flying my plane and the engine has shutdown with restart, what should I do:

- Think that the chances of that the engine restart are slim.** You don't know why it has shut down, so likely it will not restart, DO NOT RELY on it.
- Fly your plane.** Leave the throttle at mid setting and fly your plane for a dead stick landing.
- In case you see the plane begins to stall** or an uncontrolled landing is most likely, IMMEDIATELY set the trim and stick to STOP position to abort the restart function. A crash with the engine running normally ends with a fireball; a crash with the engine off is not likely to catch fire. Do not use the "digital trims" to shut down the engine, use a dedicated switch to be operated quickly.
- If the engine restart is initiated while on approach,** evaluate the speed/position of the plane is still good for a safe landing, if so, land immediately, you don't know why the engine stopped and may stop again during a "go around" but this time the aircraft may not be in an as favorable position. If the position/speed of the plane is not convenient, use the engine power to go around and plan for a normal landing, BUT land as soon as possible.
- Once the plane is on the ground,** even in normal landing or crash landing, set the transmitter in STOP position. The engine could restart and go to full power on its own; the ecu does not know when the plane is on the ground.

Can I use the restart function many times?

NO!

Restart function is an emergency procedure and places a high stress on the engine ancillary components. The starter and ignitor are fed with extra power that is not used in normal startups, this places considerable more wear on them, also the engine is subjected to abrupt temperature changes that could shorten its life.

Restart function is not the replacement of a poor fuel system. It can save a plane in particular circumstances, but it can do much more harm than good. A belly landing or landing gear damage due to a flameout induced heavy landing is more favorable than a similar landing arrival with the engine in start phase that can possibly cause a fire and result in total destruction of the model and or property.

Please Think twice before enabling the auto restart feature.

Disclaimer

There are no circumstances Jets Munt P/L or any of its Service Agents and employees will accept or be held responsible for any losses or damages the Auto Restart feature causes should the owner operator choose to enable this function.



Smart Data Terminal**HDT Screen**Default Screen

Button Back to go initial screen.

Data from FADEC.

Buttons to navigate through FADEC menus.

Initial Screen

uSD Card slot to save data from FADEC.

Initial screen with JetsMunt logo.

Button Tools, to visualize menu of the SmartDataTerminal.

Button HDT, to visualize fadec data.

Tools Screen


Button Back to go initial screen.

Button Player to go to Player Screen.

Button Radio Check to go to Radio Screen.

Button Last Shutdown to go to Last Shutdown Screen.

Button File to go to File Screen. (Only visible if uSD inserted before turn on)

Player Screen

Button Back to go initial screen.

Button Play Last run to visualize data from last run.

Button Play From to visualize data stored in Smart Data.

Radio Screen


Button Back to go initial screen.

Radio Check Screen to visualize the set points: Full power, Stop & Idle.

Last Shutdown Screen

Button Back to go initial screen.

Last Shutdown screen to visualize the last shutdown cause, RPM, Temperature and pump on shut down.

File Screen

Button Back to go initial screen.

Button Save Data to export the data from SmartData to uSD.

Button Update to update the firmware of the SmartData.